



CONICAL ANCHOR - BLUE

PART# 807AK0010

100 pcs. - 3/16" Conical Anchors
 100 pcs. - #8 Combo Screws
 1 pc. - 3/16" Slow Spiral Masonry

PART# 807AK0011

100 pcs. - 1/4" Conical Anchors
 100 pcs. - #10 Combo Screws
 1 pc. - 1/4" Slow Spiral Masonry

PART# 807AK0013

50 pcs. - 5/16" Conical Anchors
 50 pcs. - #12 Combo Screws
 1 pc. - 5/16" Slow Spiral Masonry



SUPER ANCHOR - YELLOW

PART# SUPRAK006

100 pcs. - 3/16" SUPER Anchors
 100 pcs. - #8 Combo Screws
 1 pc. - 3/16" Slow Spiral Masonry

PART# SUPRAK008

100 pcs. - 1/4" SUPER Anchors
 100 pcs. - #10 x 1 1/4" Combo Screws
 1 pc. - 1/4" Slow Spiral Masonry

PART# SUPRAK009

50 pcs. - 5/16" SUPER Anchors
 50 pcs. - #12 x 1 1/2" Combo Screws
 1 pc. - 5/16" Slow Spiral Masonry



ZAP-IN ANCHOR

PART# EZZ-PACK

50 pcs. - Zinc Zap-In
 50 pcs. - #8 x 1" Combo Screws
 1 pc. - #2 X 2" Phillips Bit



COMBO SCREW

Anchor Kits



ZAP-IN Anchors

Part #	OAL	Description	Box Qty.	Packaged
EZZ1212	1-5/16"	ZAP IN ZAMAC ALLOY	100	BOX
EZZ1212B	1-5/16"	ZAP IN ZAMAC ALLOY	2,000	BULK
EZN1212	1-3/4"	ZAP IN NYLON	100	BOX
EZN1212B	1-3/4"	ZAP IN NYLON	2,000	BULK

- ◆ Industrial Quality
- ◆ Ideal for Fastening to Drywall and Other Low Density Substrates
- ◆ Easily Removable by Simply Backing Out Screw



Hammer Drive Nail-In Anchors - Zamac

Part #	Size	Description	Drill	Box Qty.
HD14010	1/4" X 1"	MUSHROOM	1/4"	100
HD14114	1/4" X 1-1/4"	MUSHROOM	1/4"	100
HD14112	1/4" X 1-1/2"	MUSHROOM	1/4"	100

Meets or exceeds GSA Specification FF-S-325, Group V, Type 2, Class 3.

EASY TO INSTALL

No screws necessary. Just drill 1/4" hole and hammer in the anchor.

- Hollow Wall
- Solid Wall
- Concrete
- Stone
- Brick
- Plaster
- Sheet Metal



Split Drive Anchors - Zinc Plated

Part #	Size	Minimum Embedment	Drill	Box Qty.
FDA14150	1/4" X 1-1/2"	1-1/8"	1/4"	100
FDA14200	1/4" X 2"	1-1/8"	1/4"	100
FDA14250	1/4" X 2-1/2"	1-1/8"	1/4"	100
FDA14300	1/4" X 3"	1-1/8"	1/4"	100
FDA14350	1/4" X 3-1/2"	1-1/8"	1/4"	100
FDA14400	1/4" X 4"	1-1/8"	1/4"	100

Meets or exceeds GSA Specification FF-S-325, Group IV.

EASY TO INSTALL

No screws necessary. Just drill 1/4" hole and hammer in the anchor.

- ◆ Carbon Steel Construction
- ◆ Flat Head
- Concrete
- Stone
- Solid Brick