


MPT-18480 Window Shield Cutter



DESCRIPTION	PARTS NO	DESCRIPTION	PARTS NO
MOTOR HOUSING	38221-01	FRONT END PLATE	37222-22
VLAVE BUSHING	31211-02	BALL	31602-23
O RING	RX007	BEARING	B2610
O RING	RX009	SPINDLE	18483-33
THROTTLE VALVE	31211-03	BEARING (2)	B1907
SPRING	31211-05	MOTOR CLAMP	17053-25
AIR REGULATOR	31211-06	O RING	R3825
O RING	R0602	HEAD HOUSING CLAMP	11483-30
O RING	R1225	HEAD HOUSING	11483-32
VALVE SCRW	31211-09	O RING	R1002
THROTTLE LEVER	38221-09	FORK DRIVE	11483-39
PIN	P0322	BEARING	B2210
EXHAUST SLEEVE	38221-13	OIL SEAL	11483-34
INLET BUSHING	57501-09	LOCK RING	11483-35
BEARING	B2208	CUTTER SPINDLE	11483-36
REAR END PLATE	67132-16	BLADE PACKING	11483-37
DOWEL PIN(2)	P2505	LOCK SCREW	11483-38
CYLINDER	67132-18	57mm CUTTER BLADE	11483-K01A
ROTOR	37222-21	MUFFLER HOSE	MSA-006A
ROTOR BLADE(4)	67132-20	5mm HEX. WRENCH	WO005
ROTOR COLLAR	31212-18		