


MPT-18490 Cutting Shear



DESCRIPTION	PARTS NO.	DESCRIPTION	PARTS NO.
MOTOR HOUSING	38221-01	ROTOR BLADE (4)	67132-20
VAVLE BUSHING	31211-02	FRONT END PLATE	31602-24
O RING	RX007	ROLL PIN	31602-23
O RING	RX009	INTERNAL GEAR	21523-28
THROTTLE VALVE	31211-03	SPINDLE	21523-27
VALVE SPRING	31211-05	PLANET PIN (3)	31603-29
AIR REGULATOR	31211-06	PLANET GEAR (3)	21533-25
O RING	R0602	BALL BEARING	BB32120
O RING	R1225	BALL BEARING	B3212
VALVE SCREW	31211-09	CLAMP NUT	21523-31
THROTTLE LEVER	38221-09	BALL BEARING	BIR8
THROTTLE LEVER PIN	P0322	TRANSMISSION NUT	17493-30
EXHAUST SLEEVE	38221-13	SHEAR HOUSING	17493-32
INLET BUSHING	57501-09	SCREW (3)	17493-33
BALL BEARING (2)	B2208	SCREW CAP (3)	17493-34
REAR END PLATE	67132-16	BLADE PIECE	17493-35
DOWL PIN (2)	P2505	WASHER (2)	17493-36
CYLINDER	67132-18	RIGHT BLADE	17493-37
ROTOR	17492-19	LEFT BLADE	17493-38