


MPT-51610 Belt Sander (10x330mm)



DESCRIPTION	PARTS NO.	DESCRIPTION	PARTS NO.	DESCRIPTION	PARTS NO.
MOTOR HOUSING	51611-01	REAR END PLATE	51612-21	SPRING PIN (2)	51613-30
VALVE BUSHING	51611-11	ROTOR KEY	51612-17	SPRING	51613-33
O-RING	51611-10	CYLINDER	51612-20	PIN	51613-34
THROTTLE VALVE	51611-07	ROTOR	51612-19	PIN	51613-35
O-RING	51611-09	ROTOR BLADE (5)	51612-18	TENSION BAR LEVER	51613-36
O-RING	51611-06	WASHER	51612-16	GUARD SUB ASSY	51613-37
VALVE SPRING	51611-05	O-RING	51612-22	SET SCREW	51613-38
O-RING	51611-08	MOTOR CLAMP	51612-23	SCREW	51613-39
THROTTLE LEVER	51611-12	IDLE PULLEY SHAFT 10	51613-24	DUST COVER	51613-40
SPRING PIN	P0320	BEARING (2)	B0904	DRIVER PULLEY	51613-41
EXHAUST SLEEVE	51611-03	IDLE PULLEY 10 ASSY	51613-25	WASHER	51613-42
INLET BUSHING	51611-04	BRACKET 10	51613-26	SET NUT	51613-43
SPRING	51611-02	SCREW	51613-27	SHOE 10	51614-45
BALL BEARING	B2208	SCREW	51613-28	SCREW	51614-46
FRONT END PLATE	51612-15	SPRING	51613-29	BELT SANDER PAPER	MSA-3810
BALL BEARING	B1906	TENSION BAR	51613-31		