


MPT-51620 Belt Sander (20*520mm)



DESCRIPTION	PARTS NO.	DESCRIPTION	PARTS NO.
MOTOR HOUSING	51621-01	MOTOR CLAMP	51622-23
VALVE BUSHING	51621-11	IDLE PULEY SHAFT 10	51623-24
O-RING	51621-10	BEARING (2)	B1606
THROTTLE VALVE	51621-07	IDLE PULEY 10 ASSY	51623-25
O-RING	51621-09	WASHER	51623-26
O-RING	51621-06	SCREW	51623-28
VALVE SPRING	51621-05	TENSION BAR	51623-31
O-RING	51621-08	SPRING	51623-33
THROTTLE LEVER	51621-12	PIN	51623-34
SPRING PIN	P0320	PIN	51623-35
EXHAUST SLEEVE	51621-03	TENSION BAR LEVER	51623-36
INLET BUSHING	51621-04	GUARD SUB ASSY	51623-37
SPRING	51621-02	SET SCREW	51623-38
BALL BEARING	BIR6	SCREW	51623-39
FRONT END PLATE	51622-15	DUST COVER	51623-40
BALL BEARING	B1906	DRIVER PULLEY	51623-41
REAR END PLATE	51622-21	WASHER	51623-42
ROTOR KEY	51622-17	SET NUT	51623-43
CYCLINDER	51622-20	SHOE 10	51623-45
ROTOR	51622-19	Hexsagon Socket Head Bolt	51623-46
ROTOR BLADE (5)	51622-18	BELT SANDER PAPER	MSA-3820
WASHER	51622-16	NUT	51623-47
O-RING	51622-22	Hexagon Socket Head Bolt	51623-48
FINGER PAD ASSY	51623-49	Hex. Wrench 4mm	51624-01