


MPT-71690 M8 Nut Angle Pull Setter



DESCRIPTION	PARTS NO.
MOTOR HOUSING	21501-01
REVERSE BUSHING	21501-02
REVERSE SPRING	21501-03
REVERSE VALVE	21501-04
VALVE BUSHING	21501-05
THROTTLE VALVE	21501-06
O-RING	RX006
O-RING	RX007
VALVE SPRING	31211-05
O-RING	R0802
REVERSE RETAINER	21501-10
VALVE SCREW	21501-12
HOUSING GASKET	21501-13
HOUSING CAP	21501-14
SPRING PIN(2)	P2524
O-RING	R0902
HOUSING CAP WASHER	21501-18
DEFLECTOR	21501-16
O-RING	R1202
INLET BUSHING	21501-20

DESCRIPTION	PARTS NO.
THROTTLE LEVER	21501-21
SPRING PIN	P0322
MOTOR GASKET	21502-23
REAR END PLATE	21502-25
MOTOR PIN	21502-26
CYLINDER	21502-27
ROTOR	21522-21
ROTOR BLADE (5)	31212-17
FRONT END PLATE	21502-30
BALL BEARING	B2208
PLANET CONNECT GEAR	21583-25
BACK PLANET GEAR SEAT	21583-26
TRANSMISSION GEAR	21583-27
PLANET GEAR (6)	21583-29
GEAR SPINDLE (6)	31603-29
PLANET GEAR SEAT	21493-34
GEAR SPINDLE	21503-35
INTERNAL GEAR (2)	21523-28
INTERNAL GEAR COLLART	21493-39
BALL BEARING	BB28120

DESCRIPTION	PARTS NO.
PINION	21503-39
HOUSING LOCK RING	21493-40
ANGLE HOUSING	21503-41
CIRCLE OF SCREW	21503-42
OIL PLUG	30303-26
RETAINING RING	21503-44
BALL BEARING (2)	B1906
SPINDLE GEAR	21503-46
BALL BEARING	B1907
BEARING CASE	71703-55
SPINDLE	21503-49
WOODRULF KEY	31303-32
SPINDLE NUT	71703-57
TRANS NUT	71703-56
(M8) SCREW SPINDLE	71693-58
(M8) SCREW	71693-59
DOWN WASHER	71683-60
BEARING	BS0210
UP WASHER	71693-60
(M8) PULLER CAP	71683-61