



REBAR PUNCHER NOT SOLD WITH SHANK.



- ◆ Use in Rotary Hammer Action
- ◆ Industrial Quality
- ◆ Tungsten Carbide Teeth
- ◆ Twice the Speed
- ◆ Ratio System



SOLD INDIVIDUALLY. 1 PER TUBE.



Rebar Puncher - ROTARY HAMMER ACTION


Part #	Size	OAL	RPM
RG-8	1/2"	9"	HAMMER ACTION
RG-9	9/16"	9"	HAMMER ACTION
RG-10	5/8"	9"	HAMMER ACTION
RG-11	11/16"	9"	HAMMER ACTION
RG-12	3/4"	9"	HAMMER ACTION
RG-14	7/8"	9"	HAMMER ACTION
RG-16	1"	9"	HAMMER ACTION
RG-18	1-1/8"	9"	HAMMER ACTION
RG-20	1-1/4"	9"	HAMMER ACTION



Rebar Puncher Shanks

Part #	Description	OAL
RG-PLUS	SDS-PLUS	4"
RG-MAX	SDS-MAX	7-1/4"

2X SPEED



What to do when you encounter rebar:

- 1 **STOP DRILLING!!!** The sound of a rotary hammer or a carbide hammer drill bit hitting steel is much higher than when cutting concrete.
- 2 Remove the drill bit from the hole.
- 3 Mount a rebar cutter of the same diameter as the hole in an SDS-Plus Hammer Drill with the selector in the "rotary only" position.
- 4 Insert the rebar cutter into the hole and begin drilling at the suggested RPM speed only. Apply just enough pressure to grind away at the rebar. **Do Not Use Excessive Speed or Pressure on the Machine** - this will either damage or break the rebar cutter.
- 5 Once rebar is cut through, remove the rebar cutter from the hole and continue drilling with a rotary hammer or carbide hammer drill bit.

- Carbide cutters are brazed in place to keep Rebar Cutter from enlarging existing hole.

HEAD SIZES	THREAD
3/8" → 1-1/2"	1 pc.
1-3/4" → 2-1/2"	3/4"-10

⚠ REMINDER:

Rebar Cutters are problem solvers only. A 1/2" Rebar Cutter drilling through #6 (3/4") rebar dead center may result in 5 to 10 holes being drilled provided correct speed and pressure are utilized. It is not uncommon for only one piece of rebar to be cut per Rebar Cutter. Rebar Cutters *should not* be used for drilling concrete.

Rebar Cutters are not warrantied for replacement or repair.



Rebar Cutter - SDS-PLUS SHANK

Part #	Size	OAL	RPM
RBS-6	3/8"	8"	850-1200
RBS-8	1/2"	12"	850-1200
RBS-9	9/16"	12"	850-1200
RBS-10	5/8"	12"	750-1000
RBS-11	11/16"	12"	750-1000
RBS-12	3/4"	12"	600-850
RBS-13	13/16"	12"	600-850
RBS-14	7/8"	12"	600-850
RBS-16	1"	12"	500-750
RBS-18	1-1/8"	12"	500-750
RBS-20	1-1/4"	12"	450-600
RBS-22	1-3/8"	12"	450-600
RBS-24	1-1/2"	12"	350-500
RBS-28	1-3/4"	12"	350-500
RBS-32	2"	12"	350-500
RBS-40	2-1/2"	12"	350-500



Rotation Only!

SOLD INDIVIDUALLY. 1 PER TUBE.



Rebar Cutter - STRAIGHT SHANK

Part #	Size	OAL	RPM
RBC0838	3/8"	8"	850-1200
RBC1212	1/2"	12"	850-1200
RBC1916	9/16"	12"	850-1200
RBC1258	5/8"	12"	750-1000
RBC1116	11/16"	12"	750-1000
RBC1234	3/4"	12"	600-850
RBC1834	3/4"	18"	600-850
RBC1316	13/16"	12"	600-850
RBC1278	7/8"	12"	600-850
RBC1201	1"	12"	500-750
RBC1218	1-1/8"	12"	500-750
RBC1214	1-1/4"	12"	450-600
RBC1238	1-3/8"	12"	450-600
RBC1112	1-1/2"	12"	350-500
RBC1134	1-3/4"	12"	350-500
RBC1202	2"	12"	350-500
RBC1222	2-1/2"	12"	350-500



SOLD INDIVIDUALLY. 1 PER TUBE.